




Bottoms Up Control Panel V4 NAVIGATION OVERVIEW



1 POUR MODE (DEFAULT)

Fills vessel **hands-free** to the pre-programmed amount for the selected pour size (5).

2 PROGRAM SIZE

Used to set the fill amount for a hands-free pour size. Once in program size mode, press and hold desired pour size (5) until beer starts flowing. When the desired amount is reached, press the Start/Stop button (3) to stop flow, programming the amount. Finish by pressing Pour Mode.

3 START/STOP

Starts and stops the flow of beer. For use when programming a size, purging lines, topping off a pour or stopping an over pour.

4 PURGE

Placing the unit in purge/prime mode will allow the valve to stay open as long as needed to purge/prime the line. Start and stop this process with the **Start/Stop** button (3).

5 POUR SIZE

Change between three different sizes with a push of a button. Sizes must already be programmed (2).

6 ON/OFF

Turns Control Panel on and off.

7 ADJUST PROGRAMMED SIZE



Adjusts programmed size with 2% more or less beer without having to reprogram the size. **Only adjust between use.** Adjustment takes place on the next pour. The pour size selected will flash when pressed.



8 EMPTY KEG Indicator Lights

For systems that have Empty Keg Detectors (EKDs). When the keg runs dry, EKD lights flash red and beer stops pouring until the keg has been changed.



ADDITIONAL FEATURES

Change LED Brightness



To increase brightness - press  then 

To decrease brightness - press  then 

Party Mode (LEDs flash when filling)

To enter/exit party mode - press and hold  &  for 3 seconds

Admin Mode Only (locks out , &)

To enter/exit Admin Mode Only - press and hold  &  for 3 seconds

